

## Reset-Möglichkeiten für Tectalk, Tectalk FM:

Sollte der Prozessor einmal "hängen", kann man folgenden Reset durchführen:

Gerät ausschalten.

Dann **UP**, **F** und **ENTER** Tasten zusammen drücken und gedrückt halten, bis sich das Gerät eingeschaltet hat.

Tasten loslassen.

**Achtung:** Bei neueren Tectalk mit 3 Vox-Stufen verschwindet nach einem Reset zunächst die VOX Umschaltung Middle und Low. Nach einem Aus- und Wiedereinschalten sind aber alle Funktionen jedoch wiederhergestellt.

### GP1

Gerät ausschalten. Drücken Sie **Monitor**, **Power** und **Enter** (den Knopf in der Mittelstellung des auf- ab Schalters) gleichzeitig, bis sich das Gerät eingeschaltet hat. Alle Knöpfe loslassen. Der Reset-Vorgang löscht alle vom Benutzer vorher gespeicherten Daten! Das Gerät startet dann wieder mit der Werkseinstellung.

## Tectalk (New & Old), Tectalk FM Reset Procedure

PROCEDURE : Pressing the **Up**, **F** and **ENTER** (Power) button at the same time while the unit is off.

This reset procedure makes the unit return to the ' factory default ' values.

In the newer Tectalk version with 3 level vox, it was found that the Med and Low positions are disappeared in the vox mode when reset is done. But, if you turn off and turn on the unit again, this two positions are restored automatically and re-appear in the LCD.

### GP1

PROCEDURE : Pressing the **Monitor**, **Power** and **Wheel(Enter)** button at the same time while the unit is off. Resetting the unit will erase all data in the EEPROM and return to the default value.