

MECHANICAL PARTS LIST

Ref.No.	Description	RS Part No.
1	Lens (PMMA)	
2	LCD Duplex Gummed Tape	
3	Front Housing (A.B.S)	
4	LCD Mounting Plate (Steel)	
5	LCD Display T7633AKP1 (TN Type)	
6	Silicone Interconnector 'YP' Pitch:0.18mm L21.5*H6.2*W2mm	
7	LCD Back Light Plate (PMMA)	
8	Screw M2.0*4.0mm PM IRON (NI) (Three)	
9	VOL Nut M7*1.8mm (Cu)	
10	VOL Knob (A.B.S)	
11	CPU PCB	
12	Screw M2.6*4.0mm PM S/S (One)	
13	Screw Hold (Brass) (Three)	
14	RF PCB	
15	Antenna Connector Head (TNC)	
16	Antenna Nut 1/4"*1.8mm (Cu)	
17	MIC/SP Rubber Cap (Silicone Rubber)	
18	Screw M2.0*3.0mm PM IRON (One)	
19	MIC/SP PCB	
20	MIC/SP Rubber Washer (Silicone Rubber)	
21	Antenna Head (Brass)	
22	Antenna Spring OD5.8*L102.7*0.8mm Bronze	
23	Rubber Duck ANT. Sleeve (PU)	
24	Rear Case (Oil Blooming)	
25	Screw Sleeve 1.8*0.8mm (Silicone) (Six)	
26	Screw M2.0*27.50mm PB S/S (Two)	
27	PTT Key (Silicone Rubber)	
28	PTT Mount Plate (A.B.S)	
29	Belt Clip (PC)	
30	Screw M3.0*6.0mm PM S/S (One)	
31	Screw M2.0*6.0mm PM S/S (One)	
32	Screw M2.0*4.0mm BM S/S (One)	
33	Metal Washer M2.0*4.2*0.5mm IRON (One)	
34	Rubber Pad 1.8*1.8*1.5mm(+/-2mm) (Two)	
35	Battery Contact Plate (Phosphor Copper) (Three)	
36	Connector PCB	
37	BATT. CON. Rubber Ring (Silicone Rubber)	
38	Screw M2.0*5.0mm PB S/S (Four)	
39	Battery Case Lock Screw (Cu)	
40	Charger Contact Plate (Steel) (Six)	
41	Battery Back Case (A.B.S)	
42	Ni-MH Rechargeable Battery Pack 12V 700mA "AAA" G.P	
43	Battery Front Case (A.B.S)	
44	Shield Plate	
45	VCO Shield Case (Steel)	
46	Keyboard Mount Plate (PC)	
47	Speaker D36mm 8 Ohm 0.5W	
48	Speaker Net Φ34mm Nylon Black)	
49	Condenser MIC KUC F6050AL-S (-66+/-2dB)	
50	Fiber Washer OD6.0*ID4.0*H0.5 (Duplex Gummed Tape)	
51	UP/DOWN Key (Silicone Rubber)	
52	Rubber Ring For Units (Silicone Rubber)	

**DESK TOP CHARGER
MECHANICAL PARTS LIST**

Ref.No.	Description	RS Part No.
1	Lens for Charger (PMMA)	
2	Desk Top Charger PCB	
3	Charger Back Housing (A.B.S)	
4	Screw M2.0*12mm KA S/S (One)	
5	Screw M2.0*5.0mm PB (Black) (Five)	
6	Metal Contact Plate S/S (Three)	
7	Charger Front Housing (A.B.S)	
8	Rubber Pad D8*3mm Single Gummed Tape (Four) (Silicone Rubber)	

Mfr's Part No.
40-618CLC6-A00
42-2483893-A00
40-118CF51-A00
35-3181L11-A00
14-11810L0-A00
08-AB56211-A00
44-6181LE5-A00
31-3200439-A00
32-5700303-A00
40-4181V11-A00
13-1181CB1-A00
30-1260431-A00
35-0181S12-A00
13-1181R41-A00
08-01810A0-A00
32-5091803-A00
40-0181M12-A00
30-120033A-A00
13-1181M21-A00
44-90506MB-A00
35-9181A12-A00
34-4258A2A-A00
40-7181A17-A00
35-B181RB7-A00
40-0868817-A00
30-520C565-A00
40-0181P12-A00
40-0882M51-A00
40-8181B51-A00
30-1300635-A00
35-1200635-A00
30-1200415-A00
33-2042051-A00
44-81818B2-A00
35-3181013-A00
13-1181C21-A00
40-5181B12-A00
30-1200565-A00
31-5041105-A00
35-3181C11-A00
40-2182B51-A00
10-612041N-A00
40-2182F51-A00
35-6882S15-A00
35-7181015-A00
40-018CK19-A00
11-361H511-H13
44-734001E-A00
16-605006S-A00
33-0406059-A00
40-A18C012-A00
40-5181U12-A00

Mfr's Part No.
40-6181S06-A00
13-882SCHG-A00
40-118BS01-A00
30-1021295-A00
30-405026J-A00
35-3181S18-A00
40-118FS01-A00
44-81845D2-A00